

Series UAG Infrared Heater



Installation, Operation and Service Instructions

⚠ WARNING: Improper installation, adjustment, alteration, service or maintenance can cause injury, death or property damage. Read the installation, operation and service instructions thoroughly before installing or servicing this equipment.

FOR YOUR SAFETY

If you smell gas:

1. Do not try to light any appliance.
2. Open windows.
3. Don't touch electrical switches or use any phone in the building.
4. Extinguish any open flame.
5. Immediately call your gas supplier from a neighbor's phone. If you can't reach your gas supplier, call fire dept.

CONSIGNES DE SECURITE

Si vous avez une odeur de gaz:

1. N'essayez pas de lumière n'importe quel appareil.
2. Ouvrez windows.
3. Ne touchez pas commutateurs électriques ou utiliser téléphone cellulaire dans le bâtiment.
4. Éteindre toute flamme nue.
5. Appelez immédiatement votre fournisseur de gaz de chez un voisin. Si vous n'arrivez pas à joindre votre fournisseur de gaz, appelez fire dept.

FOR YOUR SAFETY

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

CONSIGNES DE SECURITE

Il est interdit d'utiliser des liquides inflammables ou degageant des vapeurs inflammables, a proximites de tout appareil fonctionnent au gaz.

Owner

Retain This Manual & Ensure Available for Service.

Improper installation, adjustment, alteration, service or maintenance can cause injury, death or property damage. Read the installation, operation and service instructions thoroughly before installing or servicing this equipment.

Installer

Provide Manual to Owner upon completion of installation!

Read and thoroughly understand these Instructions before attempting any installation



SUPERIOR
RADIANT PRODUCTS

563 Barton Street, Stoney Creek, Ontario L8E 5S1

www.superiorradiant.com



CAUTION: FIRE OR EXPLOSION HAZARD

Maintain clearance to combustible constructions as further specified in this manual. Failure to do so could result in a serious fire hazard. Heaters should not be located in hazardous atmospheres containing flammable vapors or combustible dusts. Signs should be provided in storage areas specifying maximum safe stacking height.

CAUTION: MECHANICAL HAZARD

This equipment expands and contracts with each operating cycle. The gas connection, suspension hardware and the installation itself must safely allow this movement. Failure to do so could result in serious fire or explosion hazard.

CAUTION: FIRE OR EXPLOSION HAZARD

This heater is equipped with an automatic ignition device. Do not attempt to light the burner by hand. Failure to comply could result in a serious fire and personal injury hazard.

CAUTION: MECHANICAL HAZARD

Do not use high pressure (above 1/2 psi) to test the gas supply system with the burners connected. Failure to do so could result in damage to the burner and its control components requiring replacement.

CAUTION: SERVICE LIFE RISK

Do not install equipment in atmospheres containing halogenated hydrocarbons or other corrosive chemicals. Failure to do so may lead to premature equipment failure and invalidation of the warranty. Additionally, it is recommended that the equipment be installed with a slope downward and away from the burner of 1/4" in 10' to allow start-up condensate drainage.

Table of Contents

INTRODUCTION.....	3
INSTALLATION CODES.....	3
<i>General Installation and Gas Codes.....</i>	3
<i>Parking Structures.....</i>	3
<i>Gas Supply Lines</i>	3
<i>Electrical</i>	4
<i>Venting</i>	4
GENERAL SPECIFICATIONS	5
GAS SUPPLY	5
<i>Inlet Pressure</i>	5
<i>Manifold Pressure - UAG</i>	5
<i>Inlet Connection.....</i>	5
ELECTRIC SUPPLY.....	5
FLUE AND OUTSIDE AIR CONNECTION	5
DIMENSIONAL CHARTS	6
CLEARANCE TO COMBUSTIBLES	8
INSTALLATION.....	10
INSTALLATION SEQUENCE.....	10
VENTING / COMBUSTION AIR DUCTING.....	23
GENERAL REQUIREMENTS	23
VENTED OPERATION	24
<i>Horizontal Venting.....</i>	24
<i>Vertical Venting</i>	24
<i>Common Vertical Venting.....</i>	24
<i>Common Horizontal Venting.....</i>	25
COMBUSTION AIR SUPPLY.....	26
GAS PIPING	27
GENERAL REQUIREMENTS	27
ELECTRICAL WIRING	28
GENERAL REQUIREMENTS	28
BURNER OPERATION.....	29
STARTING SEQUENCE OF OPERATION	29
MAINTENANCE	29
TROUBLESHOOTING.....	30
BLOWER MOTOR FAILS TO RUN	30
NO GAS SUPPLY.....	30
BURNER DOES NOT LIGHT.....	30
BURNER DOES NOT STAY LIT	30
TROUBLESHOOTING CHART	31
REPLACEMENT PARTS	32
WARRANTY.....	33

Introduction

Superior Radiant Products is a company in the infrared heating industry founded on the principles of product quality and customer commitment.

Quality commitments are evidenced by superior design, a regard for design detail and an upgrade of materials wherever justifiable.

Customer commitment is apparent through our ready responses to market demands and a never ending training and service support program for and through our distributor network.

Superior Radiant offers its 15 years of infrared expertise in a cost effective unitary heater design as culmination of that commitment. Series UAG models are field assembled, low intensity infrared heaters that are easy to install and maintain, and which were engineered with significant input from our customers. They are designed to provide economical operation and trouble-free service for years to come.

Important

These instructions, the layout drawing, local codes and ordinances, and applicable standards such as apply to gas piping and electrical wiring comprise the basic information needed to complete the installation, and must be thoroughly understood along with general building codes before proceeding.

Only personnel who have been trained and understand all applicable codes should undertake the installation. SRP Representatives are Factory Certified in the service and application of this equipment and can be called on for helpful suggestions about installation.

Installation Codes

Installations must comply with local building codes, or in their absence, the latest edition of the national regulations and procedures as listed below.

General Installation and Gas Codes

Heaters must be installed only for use with the type of gas appearing on the rating plate, and the installation must conform to the National Fuel Gas Code, ANSI Z223.1/NFPA 54 in the US and CSA B149.1 and B149.2 *Installation Codes* in Canada.

This heater is approved for indoor installation.

Parking Structures

Technical requirements are outlined in ANSI/NFPA 88B (USA)

Gas Supply Lines

Gas supply pipe sizing must be in accordance with the National Fuel Gas Code, ANSI Z223.1/NFPA 54 in the US and CSA B149.1 and B149.2 *Installation Codes* in Canada.

A 1/8" inch NPT plugged tap must be installed in the gas line connection immediately upstream of the burner farthest from the gas supply meter to allow checking of system gas pressure.

The appliance must be isolated from the gas piping system by closing equipment shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than ½ psi (305 Kpa)

Electrical

All heaters must be electrically grounded in accordance with the *National Electric Code, ANSI/NFPA 70* in the US, and the *Canadian Electric Code, CSA C22.1* in Canada, and must comply with all local requirements.

Venting

Refer to the *National Fuel Gas Code, ANSI Z223.1 (NFPA 54)* in the US and *CSA B149.1* and *B149.2 Installation Codes* in Canada for proper location, sizing and installation of vents as well as information on clearance requirements when penetrating combustible walls for venting purposes.

High Altitude

When installing this appliance over 4500 ft. above sea level in Canada, the appliance must be properly de-rated and installed according to local codes. In the absence of local codes the appliance must be de-rated in accordance with the most recent CSA B149 code.

In the United States for installations over 2000ft above sea level the appliance must be installed in accordance with the Current National Fuel Gas Code, ANSI Z223.1/NFPA 54.

Safety Features

This heater utilizes an airflow switch as blocked vent shut off system. This system is designed to prevent the operation of the appliance if a fresh air supply is blocked or if the flue exhaust is blocked. If this system fails to operate DO NOT ATTEMPT ADJUSTMENTS. Disconnect power to the appliance and contact a qualified service person.

Warning

Certain materials or items, when stored under the heater, will be subjected to radiant heat and could be seriously damaged.

Children and adults should be alerted to the hazards of high surface temperatures and should stay away to avoid burns or clothing ignition.

Young children should be carefully supervised when they are in the same space as the heater.

Clothing or other flammable materials should not be hung from the heater, or placed on or near the heater.

General Specifications

General Specifications

Gas Supply

Inlet Pressure

Natural Gas:	Minimum	5.0" W.C.	Propane Gas:	Minimum	11.5" W.C.
	Maximum	14.0" W.C.		Maximum	14.0" W.C.

Manifold Pressure - UAG

Natural Gas:	3.5" W.C.	Propane Gas:	10.5" W.C.
--------------	-----------	--------------	------------

Inlet Connection

Natural Gas or Propane: 1/2" female NPT

Electric Supply

120 VAC, 60 HZ, 1 Amp: 36" cord with grounded 3 prong plug

Flue and Outside Air Connection

4" O.D. male connection for flue adapter and outside air (optional) provided at the heater




Figure 1: Overall Dimensional Information




Figure 2: Component Dimensional Information

Configurations

Model	Rate (BTU/Hr)	Heat Exchanger Length (ft.)		Baffle Length (ft.)	Baffle Kit P/N
		Minimum	Maximum		
UAG-40	40,000	10'	20'	6'	CT045
UAG-60	60,000	20'	30'	6'	CT045

Table 1: Configuration Information

Note:

- Baffle CT045 is always placed in the last section of radiant tube.

The following special configurations are also approved:

60,000 BTU/Hr 15' heat exchanger with 6' Stainless steel baffle CT045 with red tab (Natural Gas Only)

A general clearance of 18” (0.5 m) in every direction is recommended (for servicing only) around each burner to ensure adequate air flow in and around the Heating System.

In addition to this it is very important to observe the minimum clearance to combustibles at all times to avoid any possibility of property damage or personal injury.

WARNING

- Clearances as marked on the heater body must be maintained from vehicles parked beneath. Signs should be posted identifying any possible violation of the clearance distances from the heater in all vehicle areas.
- Maximum allowable stacking height in storage areas should be identified with signs or appropriate markings adjacent to the thermostat or in a conspicuous location.

Table 2 lists the minimum clearance to combustible materials for various installation configurations. Note that standard clearances also apply to installation above T-bar ceilings and above decorative grills. Additional clearance may be required for glass, painted surfaces and other materials which maybe damaged by radiant or convective heat.

Combustible materials are considered to be wood, compressed paper, plant fibres, plastics, Plexiglas or other materials capable of being ignited and burned. Such materials shall be considered combustible even though flame-proofed, fire-retardant treated or plastered.

Elbows and U-bends are un-heat treated aluminized material and are installed with reflectors. Reflector miter kits are available for U-bends and elbows.

Adequate clearance to sprinkler heads must be maintained.

The stated clearance to combustibles represents a surface temperature of 90°F (50°C) above room temperature. Building materials with low heat tolerance (**such as plastics, vinyl siding, canvas, tri-ply, etc...**) maybe subject to degradation at lower temperatures. **It is the installer’s responsibility to assure that adjacent materials are protected from degradation.**

It is important to observe minimum clearance to combustibles at all times to avoid any possibility of property damage or personal injury. Clearances must be maintained from vehicles parked beneath heaters. Signs should be posted identifying any possible violation of the clearance distances from the heater in vehicle areas. Also maximum allowable stacking height in storage areas should be identified with signs or appropriate markings. Page 10 shows minimum clearance to combustible materials.






Note 1:

Bottom Shields are approved for all burner sizes. The “below” clearance (dimension C in Table 2) may be reduced by 25% when an approved Bottom Shield is used.

Caution: ***In all cases, the minimum hanging height from the floor shall be 8’***

Clearance to Combustibles

Table 2: Minimum Clearance to Combustibles

Reflector Configurations	Dim	40	60
<p>Horizontal</p> 	A	2" (5)	2" (5)
	B	18" (46)	25" (63)
	C	45" (114)	58" (147)
	D	18" (46)	25" (63)
<p>45° Reflector Tilt</p> 	A	4" (10)	4" (10)
	B	4" (10)	4" (10)
	C	40" (102)	50" (127)
	D	38" (97)	46" (117)
<p>One Side Extension</p> 	A	2" (5)	2" (5)
	B	4" (10)	4" (10)
	C	50" (127)	58" (147)
	D	35" (89)	38" (97)
<p>Two Side Extension</p> 	A	2" (5)	2" (5)
	B	9" (23)	16" (41)
	C	50" (127)	58" (147)
	D	9" (23)	16" (41)
<p>U-Tube, Horizontal</p> 	A	-	2" (5)
	B	-	25" (64)
	C	-	59" (150)
	D	-	22" (56)
<p>Unvented</p>	Above	12" (30)	12" (30)
	End	26" (66)	26" (66)
<p>Vented</p>	End	18" (46)	18"

Installation Sequence




Figure 3: General Overview of Installation

A general ordered sequence for installation is provided below for reference.

HANGERS INSTALLATION

- Suspension mechanism must allow for lateral tubing expansion. A minimum 12" length welded link chain with a working load limit of at least 200 lbs. is recommended (refer to Figure 4 for more details). **SRP recommends and make available "quick links" for connecting chain. If any open ended "S" hooks and turnbuckles are used, the open ends must be closed to avoid unhooking chain with inadvertent contact.**
- Locate hanging chain at predetermined suspension points in the structure. **It is required that the first 2 hangers** be about 8' to 9'. Thereafter, 10' apart on average is acceptable for the remainder of the heat exchanger. At no time should hangers be more than 12' apart, (see Figure 5).
- Each hanging point must hold a minimum of 200 pounds
- Heater must fire horizontally

Installation




Figure 4: Suspension Mechanism

- Install the tube and reflector support hanger on the chain with “Quick Links”, refer to Figure 4 & Figure 5. Anchors, Beam Clamps & Eye Bolt must be of minimum 200 pound capacity.




Figure 5: Hanging Points

- Place the first (*flanged, aluminized*) tube in the first two hangers (Figure 6). Be sure the flange is toward the intended burner location. The other end of the tube should have the first coupling already loosely fitted.

TUBE INSTALLATION

- Always use all the hangers supplied. As a rule the combustion tube (first tube) utilizes 2 hangers and thereafter 1 hanger per 10' section. **It is required that the first hanging point be 2" to 8" from the burner mounting flange, and tube weld seam must face down**, refer to Figure 6 for more details.




Figure 6: Installation of First section of Flanged Tube

- For all remaining tubes, fit the end of the tube with a coupling refer to Figure 7, (the coupling should be loose).





Figure 7: Installation of Heat Exchanger Tube and Coupling

Installation

- Tighten the cradle loops of the first hanger with the “J-Bolt” found in the burner box, to snugly hold the combustion tube from rotating see Figure 8.

Note: For all coupling joints, ensure that the tube joint is in the center of the coupling length, and that the overlap joint of the coupling is above the centerline of the tube. Also ensure that the weld seam on ALL tubes is facing down.

Note: *In order to obtain smoothly sealed coupling liners, tighten each of the coupling bands progressively and alternately. Tightening one band completely before the other may result in an undesirable wrinkle in the liner. **Be sure not to over torque the coupling. (Torque coupling to 15-25 lbf-ft).***



- Continue placing tubes, couplings and reflectors to complete the heater assembly. Ensure heat exchanger sections line up straight. Couplings should be tightened as heat exchanger is placed, since it is more difficult to do so once the reflector is in position.

HEATER AND BAFFLE INSTALLATION

- Locate the burner gasket provided and bolt the burner in place on the tube flange with provided hardware. **Burner must never be installed in a tilted position.** The sense electrode of the burner cup should be in the 12 o'clock position (Figure 9).




Figure 9: Burner Gasket Installation

Install the baffle at the end of the heat exchanger. The small tab on the baffle is folded over the end of the tube and clamped in place by the vent connector and vent system, refer to Figure 10.





Figure 10: Baffle Installation

Installation

- A general overall view of the tubes and reflector hangers are shown in Figure 11 below.

Figure 11: Overall view of Tubes and Reflector Hangers



REFLECTOR INSTALLATION

- Slide a reflector section into place within the support hanger, (Figure 12)




Figure 12: Reflector Installation

- Install reflector support brackets, one at each reflector overlap position, and one in the middle of each 10' reflector length. Figure 13 shows the installation of the reflector support bracket.




Figure 13: Reflector Support Bracket Installation

Installation

Note: Reflectors should overlap adjacent reflectors 4" to 6". Be sure not to tile reflector sections; that is, reflector sections must be either above both adjacent reflector sections, or below both adjacent reflector sections..

Secure every second reflector overlap together with a minimum of 2 - #8 x 3/8" inch long screws (not supplied), and secure reflector to the reflector bracket at this point by tightening down #8 x 1 1/4" screws supplied with reflector brackets (Figure 14). The remaining reflector overlap joints and reflector brackets are left loose to accommodate system movement.




Figure 14: Reflector Overlap Illustration

ELBOW AND “U-TUBE” INSTALLATION

- If required by the heater layout, install 90° elbows or U-tube where indicated. Refer to Figure 15 & 16 for details.

Note: Elbows or U-tubes are installed with reflectors. You must use mitered reflector kit(s) to do so.




Figure 15: 90° Elbow Assembly Detail

- Elbows or U Tubes must be located not less than 10' from the burner.

Installation

MITERED REFLECTOR INSTALLATION




Figure 16: U-Tube Reflectors Installation

SIDE REFLECTORS & BOTTOM SHIELDS

- If used, install side shields (reflectors) and/or bottom shield as required. Refer to Figure and Figure for details.
- Side shields are 124" long. Fasten one side shield per reflector with #8 x 3/8" screws. Use three side shield brackets per side shield. Space about 48" apart, refer to Figure 17.




Figure 17: Side Shield Overlap

Installation

BOTTOM SHIELD REFLECTOR INSTALLATION

- Bottom shields need not overlap. Each 5' section is held with two support brackets (see Figure 18).




Figure 18. Bottom Shield Installation

DECO-GRILLE (OPTIONAL)

Series UAG heaters are approved for the addition of Deco-Grill directly to the heater reflector. See below for details.




Figure 19: Deco-Grille and Heater Installation

Venting / Combustion Air Ducting

General Requirements

- Refer to the *National Fuel Gas Code*, ANSI Z223.1 (NFPA 54) in the US and CSA B149.1 and B149.2 *Installation Codes* in Canada, as well as all local requirements for general venting guidance.
- Series UAG Infrared Heaters may be installed vented or unvented.
- Series UAG Infrared Heaters may be vented horizontally or vertically using conventional venting materials.
- If heater is to be vented horizontally, the vent from building must:
 - Be not less than seven feet above grade when located adjacent to public walkways.
 - Terminate at least three feet above any forced air inlet located within ten feet.
 - Terminate at least four feet below, four feet horizontally from or one foot above any door, window, or gravity inlet into any building.
 - Be located at least 12" from any opening through which vent gases could enter a building.
 - Extend beyond any combustible overhang.
 - Be installed at a height sufficient to prevent blockage by snow.
- Outside air supply may be directed to the heater horizontally or vertically.

IMPORTANT

- Maximum total vent length allowed for any model heater is 30'.
- Maximum total fresh air inlet duct length allowed for any model heater is 30'.
- Total of vent length plus outside air supply duct length cannot exceed 50' for any heater with minimum heat exchanger length.
- If condensation in the vent pipe or outside air supply duct is a problem, shorten or adequately insulate the section.
- Install a minimum 18 inch (30 cm) straight length of duct for air intake or vent before any Tee or elbow.
- Do not install any elbow or 45 fitting to bring vent lower than the horizontal tube system.

Note: The above stated requirements assume a maximum of 2 elbows in the total combination of vent and air supply duct. Subtract 5' of allowable length for each elbow if 3 or more elbows are used.

Vented Operation

In all cases, be sure vent pipes and outside air supply ducts are sealed with approved sealant, such as high temperature RTV silicone. Double wall venting (B vent) may not require sealant.

Horizontal Venting

- When venting through combustible walls, use approved vent terminal Tjernlund VH1-4, or SRP supplied deflector vent terminal CT011 with an approved insulating thimble CS006.
- When venting through non-combustible walls, use SRP supplied deflector vent terminal. Recommended extension of the terminal past the outside wall surface is 18" inches minimum.




Figure 20: Horizontal Venting

Vertical Venting

- Minimum vent pipe size is 4" for an individual heater. Additional vent pipe sizes as required to accommodate multiple heaters venting through a common roof vent are defined in the appropriate gas installation code. (Refer to common venting section below).
- Use of an approved thimble to pass through combustible roof materials is required.
- Use of an approved vent cap is required.
- Check local codes for vertical vent size

Common Vertical Venting

- Common vent sizing information is defined in the appropriate gas installation code (Refer to ANSI Z223.1 and CSA B149.1 and B149.2 for sizes and installation information).
- For vertical venting refer to ANSI Z223.1 and CSA B149.1 and B149.2
-
- Connection locations to the common vent should be offset to avoid pressure interferences between heaters, refer to ANSI Z223.1 and CSA B149.1 and B149.2

Venting / Combustion Air Ducting




Figure 21: Common Vertical Venting

Common Horizontal Venting

- All heaters connected to a common horizontal vent must operate at the same time. Connect the electrical circuit to the same thermostat to ensure simultaneous operation.
- Fresh air supply **CANNOT** supply other burner systems.
- Refer to Figure 22 for detailed Common Horizontal Venting guidelines.




Figure 22: Common Horizontal Venting

Combustion Air Supply

- An outside combustion air supply is strongly recommended.
- The outside air terminal must be of an approved type, and should be located at an elevation equal to or below the vent terminal elevation to prevent back-venting of flue gases into the burner compartment.
- Install single wall pipe or PVC pipe and fittings with a 12-inch linear section of flexible duct to allow movement of the heater. Do not use flexible duct throughout the entire length of fresh air duct. This may cause nuisance air switch tripping.




Figure 23: Installation of Outside Air as supply for Combustion

Gas Piping

General Requirements

- The gas meter and service must be sufficiently large to supply gas to the connected building gas load including the heating equipment and any other gas fired equipment. Additionally, the gas distribution piping must be designed according to local and national ordinances. Generally (low pressure) systems designed with a maximum ½" W.C. total pressure drop meet this requirement.
- Gas supply pipe sizing must be in accordance with the *National Fuel Gas Code*, ANSI Z223.1 (NFPA 54) in the US and CSA B149.1 and B149.2 *Installation Codes* in Canada.
- Before connecting burners to the gas supply system, verify that high pressure testing of the system has been completed. Failure to do so may expose the burner components to damaging high pressure, requiring replacement of key components.

Flexible gas connectors of approved type must be installed as shown in Figure 24, in one plane, and without sharp bends, kinks or twists. A smooth loop of approximately 12" in diameter is best. Failure to install the gas connection in the approved manner will result in a hazardous and potentially deadly situation due to the movement of the heat exchanger and burner in the normal course of operation.




Figure 24: Flexible Gas Connections

General Requirements

Heaters are normally controlled by line voltage (120V) or low voltage (24V) thermostats. Line voltage thermostats are wired directly while low voltage thermostats use a relay. In all cases, heaters must be grounded in accordance with the *National Electric Code, ANSI/NFPA 70* in the US, and the *Canadian Electric Code, CSA C22.1* in Canada, and must comply with all local requirements. Heaters may also be controlled with a manual line switch or timer switch in place of the thermostat. Refer to Figure for guidance on electrical wiring of heaters.

If any of the original wire as supplied with the heater must be replaced, it must be replaced with wiring having a rating of at least 105°C temperature service and 600 volts capability.




Figure 25: Wiring Diagram Series UAG

Starting Sequence of Operation

- Turn the thermostat up. When the thermostat calls for heat, the blower motor will energize.
- When the motor approaches nominal running RPM, the air-proving switch closes and activates the ignition module.
- The ignition module, after a pre-purge period of approximately 30 seconds, energizes the igniter. Additionally, the gas valve is energized for this ignition trial period of 15 seconds.
- If a flame is detected, the ignition sensing rod "reads" a rectification signal and the gas valve remains open. The sparking stops when the flame signal is established.
- If no flame is detected, the gas valve closes and a 30 sec inter-purge period begins. After the inter-purge, the module repeats the trial for ignition period. If flame is still not established, a third and final inter-purge followed by a final ignition trial cycle begins. After three trials, the module will lockout for a period of approximately 1 hour or until reset. (*Reset is accomplished by removing power from the module for at least 5 seconds.*) After this 1-hour period, the module re-attempts the full ignition sequence.
- When using a 24V thermostat and the heat requirement has been met and the thermostat opens, the burner shuts off but the fan continues to run for approximately 30 seconds. This is referred to as a post purge. This allows the products of combustion to be removed from the heat exchanger to avoid nuisance condensation and increase heat exchanger life.
- When using a line voltage thermostat and the heat requirement has been met and the thermostat opens, the burner and fan shut off with no post purge.

Maintenance

For best performance, the certain minimal maintenance procedures should be performed before each heating season:

- Before performing any services or maintenance, shut off gas and electrical supply to heater.
- Check condition of forced air blower scroll and motor. Dirt and dust may be blown or vacuumed from the blower.
- Check condition of burner. Remove any foreign objects or debris from inside the burner box or burner cup.
- Inspect the igniter. Replace igniter if there is excessive wear or erosion, breakage or other defects.
- Be sure the burner observation window is clean and free of cracks or holes. Clean or replace as necessary.
- Check the flue pipe for soot or dirt and reattach to the heater after cleaning as necessary.
- The reflector sections may be cleaned by wiping with a damp cloth.
- A service agency qualified to adjust and repair infrared heaters should be engaged for service other than routine maintenance.
- Be sure vent terminal and fresh air inlet are free from obstructions. If either pipe is restricted, the safety air switch will not operate properly, and the heater could fail to operate.
- Check the inside of the heat exchanger tube visually with a flashlight. If carbon or scale are present, scrape or otherwise remove deposits (a wire brush works well)

Troubleshooting

Blower Motor Fails to Run

- Is the thermostat calling for heat? Is there 115V at the burner receptacle?
- Check blower side door for seal. Repair as necessary.
- Check blower for obstructions. Replace blower if necessary.

No Gas Supply

- Check to see if manual supply valve to heater is ON.
- Check to see if gas valve knob on heater gas control is ON.
- Supply gas pressure can be checked at 1/8" NPT pressure tap in gas supply system.
- Is combination gas control opening? No manifold pressure indicates valve is closed. Gas pressure downstream of gas control can be measured by connecting a manometer to pressure tap on control. If the valve is closed, either the gas valve or the ignition module is faulty.


Burner Does Not Light

- Is spark visible through site glass during ignition trial? If no, further electrical checks by a qualified service person are required.
- Check to see if gas lines were properly purged of air.
- Check inlet and outlet gas pressure during ignition period.
- Check for proper orifice and air plate.

Burner Does Not Stay Lit

- Check ground wire continuity.
- Check insulation on the igniter leads.
- Measure flame signal current; it should be between 2 to 6 micro amps dc. Minimum 0.8 micro amps.
- Clean flame rod if necessary.
- Replace module if necessary.



Troubleshooting Chart



Replacement Parts

ITEM #	PART #	DESCRIPTION
①	CE057	INDICATOR LIGHT
②	CE015C	IGNITION MODULE
③	CG142	UAG-HONEYWELL VALVE TRAIN REPLACEMENT KIT - NAT.
	CG143	UAG-HONEYWELL VALVE TRAIN REPLACEMENT KIT - LPG.
④	CE058	TRANSFORMER -- UAG
⑤	CE133	BLOWER MOTOR
⑥	CH007	BLOWER GASKET

ITEM #	PART #	DESCRIPTION
⑦	CE003	FLAME SENSOR ELECTRODE
⑧	CE002	SPARK ELECTRODE
⑨	CE006	IGNITION WIRE
⑩	UG001P	BURNER CUP
	UG007	BURNER CUP ASSEMBLY (C/W ELECTRODES)
⑪	CH011	SIGHT GLASS ASSEMBLY
⑫	CE020	AIR SWITCH - MODELS - 40,000 & 60,000 BTU
⑬	CE010	POWER CORD
⑭	CH001	BURNER GASKET
⑮	VS022	AIR INLET KIT



SERIES UAG WARRANTY

The manufacturer warrants to the original owner that the product will be free of defects in material and workmanship as described below.

Series	Component	Warranty Period			
		3 Years	5 Years	7 Years	10 Years
UAG	Burner & Controls	*			
	Hot Rolled Heat Exchanger w/o Post Purge		*		
	Aluminized Heat Exchanger w/o Post Purge			*	
	Hot Rolled Heat Exchanger with Post Purge			*	
	Aluminized Heat Exchanger with Post Purge				*

The Manufacturer's obligation under this warranty is limited to repair or replacement, F.O.B. its facility, of the defective part. In the case of replacement parts, the warranty period shall be the longer of the original warranty or a period of 12 months from the date of purchase. In no event shall the Manufacturer be liable for incidental expense or consequential damages of any kind.

This warranty does not cover any shipping, installation or other costs incurred in the repair or replacement of the product. No materials will be accepted for return without authorization.

This warranty will not apply if in the judgment of the Manufacturer, the equipment has been improperly installed, unreasonably used, damaged or modified.

This warranty will not apply to damage to the product when used in corrosive atmospheres and in particular atmospheres containing halogenated hydrocarbons. No person is authorized to assume for the Manufacturer any other warranty, obligation or liability.

THE REMEDIES PROVIDED FOR IN THE ABOVE EXPRESS WARRANTIES ARE THE SOLE AND EXCLUSIVE REMEDIES. NO OTHER EXPRESS OR IMPLIED WARRANTIES ARE MADE INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE OR PURPOSE.